

Dawlance
ڈاؤلینس ریلائبل ہے!

Dawlance

ELECTRIC KETTLE

This owner's guide book is for the following 2200 watts electric kettle model:

DWEK 7200



1. Read these instructions carefully before installing and operating the electric kettle. Keep them for further reference.
2. Record in the space below the SERIAL NO. found on the name plate on your kettle and retain this information for future reference.

SERIAL NO.:

ڈاؤلینس ریلائبل ہے!

CONTENTS

IMPORTANT SAFETY INSTRUCTIONS	3
KETTLE PARTS.....	4
BEFORE FIRST USE.....	5
CLEANING.....	5
CORRECT DISPOSAL OF THIS PRODUCT.....	5

SPECIFICATIONS


Model:	DWEK-7200
Rated Voltage:	220-240V
Rated Frequency:	50 / 60 Hz
Rated Input Power:	1850 W - 2200 W
Capacity:	1.7 L
External Dimensions(WxDxH):	232mm x 160mm x 230mm

IMPORTANT SAFETY INSTRUCTIONS

- This appliance can be used by children aged from 8 years and above if they have been given adequate supervision or instructions concerning use of the appliance in a safe way and if they understand the hazards involved. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised. Keep the appliance and its cord out of reach of children aged less than 8 years.
- Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given adequate supervision or instructions concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- If the kettle is overfilled, boiling water may be ejected.
- The kettle is only to be used with the stand provided.
- Please read these instructions carefully before using the water kettle for the first time.
- Before you connect the kettle to the mains supply, make sure that the voltage indicated on the rating plate, located on the bottom of the water kettle matches the mains voltage in your home. If it does not, contact your dealer and do not use the kettle.
- The kettle will switch off automatically when the water has boiled. If you want to stop the heating process before the kettle automatically switches off, press the On/Off switch handle up.
- After the kettle has switched off automatically (or has been switched off manually) it may need time to cool down. After 15-20secs, the kettle can be switched on again.
- Always fill the kettle with water before switching it on.
- If the kettle ever boils dry, the power indicator will go on. Lift the On/Off switch and unplug. Allow 15 minutes to cool down before refilling it with cold water. The safety cutout will automatically reset during this time.
- Place the kettle on a stable flat surface.
- Ensure that the kettle is switched off before removing it from its stand.
- Do not remove the kettle from its stand during operation. Do not open the top lid during operation.
- Never immerse the kettle or cord in water or any other liquids. Do not allow any liquids to penetrate the electrical parts of this kettle.
- Prevent children from pulling on the mains cord or knocking the kettle over.
- Ensure that the mains lead does not overhang the worktop surface.
- Before cleaning the kettle disconnect from the power supply and wait until it cools down.

- Only use the cord supplied with this kettle. If a replacement is required, only approved components may be used.
- The outside surface of the kettle may get hot during use, please take care when using the kettle.
- Never fill in water more than the maximum acceptable water level.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Keep the electrical appliance out of reach from children or infirm persons. Do not let them use the appliance without supervision.
- This appliance is intended to be used in household and similar applications such as :
 - Staff kitchen areas in shops, offices and other working environments;
 - Farm houses;
 - By clients in hotels, motels and other residential type environments;
 - Bed and breakfast type environments.

KETTLE PARTS



BEFORE FIRST USE

Before first use, it is recommended to operate the kettle for 2 or 3 times following the instructions above, this will remove any dust or residues remaining from the manufacturing process.

- Take up the jug kettle from the base before filling.
- To fill the jug kettle, open the cover by pulling the lid button inwards, then fill to the desired level (min0.75L-max.1.7L), close the lid by pressing it down until it clicks into place.
- Plug the power supply cord into the main, press the On/Off switch down, the power indicator lights up.
- When the water has boiled the kettle will automatically switch itself off. You can stop the boiling process at any time by lifting the On/Off switch. The power indicator will go out.

Note: Do not open the lid when steam is coming out of the spout.

Kettle is only to be used with the stand provided.

CLEANING

- First read the instructions in the section titled "Important safety instructions".
- Avoid using abrasive cleaning agents.
- Empty the kettle and allow it to cool down, open the lid, lift out the filter, rinse the filter under warm water and brush off any impurities.
- Refitting is the reverse of removal.
- Half fill the kettle with tap water and add the juice of 1 lemon to the water.
- Boil this mixture and allow it to stand for 15 minutes. Re-boil the mixture and allow it to stand a further 15 minutes. Re-boil this mixture a third time then rinse the kettle well.

CORRECT DISPOSAL OF THIS PRODUCT



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.

DAWLANCE CUSTOMER SERVICE CENTERS NETWORK

Head Office: Dawlance Center 7/4, Civil Lines-9, Dr. Zia uddin Ahmed Road, Karachi.

Ph: (021) 35652450-9 **Fax:** (021) 35674643 **Email:** service@dawlance.com.pk

For All Complaints, Please dial

03-111-11-7359(RELY) / 021-111-11-7359(RELY)

● KARACHI (ZONAL OFFICE)

Banglow# 1 St 9 Bahadur Yar Jung Society Blk 7/8 Mian Sheed E Millat Road Khi. Ph 021-34370344-45

● KARACHI

L-2526 Darakshan Society, Malir Kala Board Near Malir Town Office, Quaidabad. Ph:(021) 34518261, 34518269

● FAISALABAD (ZONAL OFFICE)

P-369, Jinnah Colony Behind Badar Bakery. Ph:(041) 2619774, 2634067

● SUKKUR

H No. 1054/1-A, Bandar Road, Opp. Jama Masjid Near Edhi Center, Ph:(071) 5625842, 5625214

● SARGODHA

H No. 43-44, Dar Us Salama Rd, Sultan Colony Near Chenone Plaza, Sargodha Cantt, Ph:(048) 3765905-6

● KARACHI

Plot # C-28C, 24th Commercial Street DHA Phase II Ext, DHA. Ph:(021) 36066798, 34223739

● HYDERABAD

Plot # A/ 151-A, Block C, Unit #2, Latifabad. Ph:(022) 3864640, 3811216

● SAHIWAL

H #24/W, Scheme#2, Fareed Town. Ph:(040) 4551313-3

● QUETTA

Gurdatt Singh Road, House # 53/3, Opp. Special Boys High School, Ph:(081) 2833406

● MULTAN

H.# 12-A, Opposite Mohammad Arcade, Near Khana-e-Farhang Iran. Ph:(061) 6524355, 4782835

● LAHORE (ZONAL OFFICE)

309A, Shadman Colony Shadman. Ph:(042) 37533985-8

● JHELUM (ZONAL OFFICE)

B-II- IR, Mohammadi Chowk, Ph:(054) 4610578, 4623236

● RAWALPINDI (ZONAL OFFICE)

36 - C - 1, Satellite Town. Ph:(051) 111-11-RELY(7359), 4841074, 4451101

● PESHAWAR

House No: 06, Shadab Street, Near Gulshan Haji Plaza, University Road, Peshawar. Ph:(091) 5841281, 5842540

● HASSANABDAL

CB - 284 / 1, Near Barrier # 3, Mall Road, Lalazar Colony, Wah Cantt. Ph:(051) 4510895, 4530206

● LAHORE

2 / 1, Ghulam Ahmad Park, Near Saddar Round About. Ph:(042) 6684769, 8402037

● GUJRANWALA

Plot # 1, Street 1, Fatima Homes, Bukhari Road, New Railway Station. Ph:(055) 111-11-RELY(7359), 3856442, 3857602

● ISLAMABAD

4- Chenab Market, Street No. 34, G-7 / 1, Behind ZTE. Ph:(051) 2202977, 2204498

● SIALKOT

St # 1, Nishat Park, Paris Road, Opp. Chamber of Commerce Building Ph:(052) 4290502-3

Zonal Offices:

Customer Service Centre Karachi

Customer Service Centre Faisalabad

Customer Service Centre Lahore

Customer Service Centre Jhelum

Customer Service Centre Rawalpindi

Central Store

(021)-34141501

(041)-2638129

(042)-35960272

(054)-4271406

(051)-4846409

(021)-34141444

